

How does the parking feature function?


44 Thu, Jan 28, 2021 Call Features

Question

How does the parking feature function?

Answer

Parking must be enabled by toggling the option to the position. Once on, park lines become available to be programmed on devices. Parking extensions should begin with extension 9800 with a minimum of 5 and a max of 99. Each line is its own extension. If the lot size is set to 5, you will have extensions 9801, 9802, 9803, 9804, and 9805 available. You can adjust the time a call can be placed on park by using the Parking Time dropdown and selecting a time (in seconds.)



- Parking** Toggle to to enabled parking extensions.
- Parking Extension** The extension parking will begin with. This should be set to 9800. Available lines will start at 9801.
- Parking Lot Size** The number of parking lines available.
- Parking Time** Length of time a call can sit on the park line. This is measured in seconds.
- Parking Hints** Can be enabled or disabled to allow hints for parking.

Applies To

MAXvoice
Call Flow