

How do I update speed dials on my device?


66 Mon, Feb 5, 2024 Device Settings

Question

How do I update speed dials on my device?

Answer

On a particular device's information page, the BLF (busy lamp field) allows the addition and removal of speed dials that will appear on the device's line keys. The device must be rebooted for the changes to appear on the phone.



The screenshot shows two sections of the MAXvoice Device Settings interface. On the left, the 'Add New Watch Dial' section is displayed, featuring fields for 'Extension *' (a dropdown menu with 'Please select-') and 'Label *' (a text input field containing 'Label'). A blue 'Save' button is located at the bottom right. On the right, the 'BLFs' section is shown, listing six entries in a table format. Each entry includes the extension number, the label, a 'Watch Enable' status (all marked 'Yes'), and a row of three buttons for managing the entry: up and down arrows for reordering and a delete icon.

Extension	Label	Watch Enable	Action
1032	Kevin Miller	Yes	↑ ↓ 
1123	Chris Risko	Yes	↑ ↓ 
1011	Doug Fagan	Yes	↑ ↓ 
1003	Patricia Monday	Yes	↑ ↓ 
1019	Kathy McVeigh	Yes	↑ ↓ 
1015	Susan Graham	Yes	↑ ↓ 

Add New Watch Dial The dropdown menu includes a list of all available extensions within the group. Once selected the label line will populate automatically. Watch dials will appear on your phone and will light up when the user is on a call. Saving this will place the extension to the **BLFs** section to the right.

Add New Speed Dial Here you can add a full 10-digit number or 4-digit extension for 1-touch dialing. You are required to create a label for each speed dial. If that extension is on a call and added as a speed dial you will not have a light on the phone indicating call status. When pressed, the programmed number will be dialed by the system.

BLFs All watch and speed dials will be added in the order in which they were created. Using the   buttons will adjust the position of the extension up or down. Using the  button will remove the selected number from the BLF.

Applies To

MAXvoice